



## 7121P\_7128\_7116P\_7098\_7102

Semi-Attached Back and Loose Seat Cushion Standard Nails: #2N (On Rolled Arm Front Panel)

P = Power S = Sock Arm B = Box Back

#### (1) 7121PSB Alexander LAF Power Reclining Loveseat

Overall Dimensions: H41 W57 D37 in. Seat Dimensions: HH200 W49 D20 in.

Standard Pillow: One #21 WR

### (1) 7128XXB Alexander Conversation Wedge

Overall Dimensions: H41 W39 D37 in.

Seat Dimensions: H20 D20 in. Standard Pillow: One #21 WR

#### (1) 7116PXB Alexander Armless Power Recliner

Overall Dimensions: H41 W24 D37 in. Seat Dimensions: H20 W24 D20 in.

#### (1)70098 Barry Console

H27 W15 D36 in. **Straight Console** 

# (1) 7102XSB Alexander Right Arm Facing Chaise

Overall Dimensions: H41 W30 D62 in. Seat Dimensions: H20 W27 D45 in. Standard Pillow: One #21 WR

As Shown

Fabric: Tilt Charcoal

Contrast Pillows: Braisai Herb