



## **9031-PRBU\_9028-XXBU\_9032-PRBU**

### **9031-PRBU LAF Power Recline Sofa**

H39 W80 D39 in.

Seat Height: 20 in.

Seat Depth: 20 in.

Standard Throw Pillows: (2) #21 WR

Wall Clearance: 0"

Power Reclining Mechanism

#### **Options Shown:**

**R** = Rolled Arm

**B** = Box Edge Back

**U** = Upholstered Base

### **9028-XXBU Stationary Wedge**

H39 W69 D39 in.

Seat Height: 20 in.

Seat Depth: 20 in.

Standard Throw Pillows: (1) #21 WR

Wall Clearance: 0"

#### **Options Shown:**

**XX** = No Arm

**B** = Box Edge Back

**U** = Upholstered Base

### **9032-PRBU RAF Power Recline Sofa**

H39 W80 D39 in.

Seat Height: 20 in.

Seat Depth: 20 in.

Standard Throw Pillows: (1) #21 WR

Wall Clearance: 0"

Power Reclining Mechanism

#### **Options Shown:**

**R** = Rolled Arm

**B** = Box Edge Back

**U** = Upholstered Base