

FIRST FOUR DIGITS
INDICATE THE FRAME

9

0

POWER RECLINE*

ARM STYLE**

BACK CUSHION

BASE

P

Recliners require ZERO wall clearance.
Standard release: Button

Standard Dimensions:
 All Frames have the same overall dimensions unless otherwise noted.*
 Overall Depth: 39" Seat Depth: 20"
 Overall Height: 39" Arm Height: 25"
 Seat Height: 20"



Example: 9030PTBU = Zero Wall Power Recliner Sofa
 9030-Sofa Power Recliner, P-Power, T-Track Arm, B-Box Back, U-Upholstered Base

1
 CHOOSE YOUR FRAME STYLE

9010P-□□□
 Chair Power Recliner
 W42

9011P-□□□
 Left Arm Facing Chair Power Recliner
 W36
 Standard: (1) #21 WR 21" Pillow

9012P-□□□
 Right Arm Facing Chair Power Recliner
 W36
 Standard: (1) #21 WR 21" Pillow

9013-□□□
 Armless Chair
 STATIONARY
 W27
 Pillows N/A

9016 P-□□□
 Armless Chair Power Recliner
 W27
 Pillows N/A

9020P-□□□
 Love Seat Power Recliner
 W65
 Standard: (2) #21 WR 21" Pillows

9021P-□□□
 Left Arm Facing Love Seat Power Recliner
 W57
 Standard: (1) #21 WR 21" Pillow

9022P-□□□
 Right Arm Facing Love Seat Power Recliner
 W57
 Standard: (1) #21 WR 21" Pillow

9028-□□□
 Wedge
 STATIONARY
 W69
 Standard: (1) #21 WR 21" Pillow

9030P-□□□
 Sofa Power Recliner
 W86
 Standard: (2) #21 WR 21" Pillows

9031P-□□□
 Power Left Arm Facing Recliner Sofa
 W80
 Standard: (1) #21 WR 21" Pillow

9032P-□□□
 Power Right Arm Facing Recliner Sofa
 W80
 Standard: (1) #21 WR 21" Pillow

2
 CHOOSE YOUR ARM STYLE

S - Sock Arm
 —

S

R - Rolled Arm*
 —

R

*#2N BRASS NAIL TRIM STANDARD WHEN ORDERED IN LEATHER

T - Track Arm**
 —

T

**TRACK ARM WIDTH IS 3" SHORTER PER ARM

* Note:
 Throw Pillows are standard on Fabric Upholstered Frames.
 Throw Pillows not standard on Leather Upholstered Frames.
 R and S Arm Sofas = 86". T Arm Sofas = 80"
 Track arm width is 3" shorter per arm.

3
 SELECT A BACK CUSHION

B - Box Edge Back Cushion
 —

B

BACK PILLOWS ARE SEMI-ATTACHED

K - Knife Edge Back Cushion
 —

K

BACK PILLOWS ARE SEMI-ATTACHED

4
 CHOOSE A BASE OPTION

T - 8.5" Traditional Skirt
 —

T

U - Upholstered Base*
 —

U

*#2N BRASS NAIL TRIM STANDARD WHEN ORDERED IN LEATHER

SAMPLE CONFIGURATIONS



9021P POWER LEFT ARM FACING RECLINER LOVESEAT
 H39 W80 D39
 Arm H25 Seat H20 D20
 Overall Layout: 59"

9028XBU WEDGE
 H39 W69 D 39
 Seat H20 D20

9022P POWER RIGHT ARM FACING RECLINER LOVESEAT
 H39 W80 D39
 Arm H25 Seat H20 D20
 Overall Layout: 59"

OPTIONS SHOWN:
 Arm: T-Track
 Back: B-Box Back
 Base: U-Upholstered



L9030PSBU ZERO WALL POWER RECLINER SOFA
 H39 W86 D39
 Arm H25 Seat H20 W20 D20
 Wall Clearance: 0"
 Overall Layout: 59"
 Semi-Attached Back

OPTIONS SHOWN:
 Arm: S-Sock
 Back: B-Box Back
 Base: U-Upholstered



9010PRKU ZERO WALL POWER RECLINER CHAIR
 H39 W42 D39
 Arm H25 Seat H20 W20 D20
 Wall Clearance: 0"
 Overall Layout: 59"
 Semi-Attached Back

OPTIONS SHOWN:
 Arm: R-Rolled
 Back: K-Knife Edge Back
 Base: U-Upholstered



9031PRBU POWER LEFT ARM FACING RECLINER SOFA
 H39 W80 D39
 Arm H25 Seat H20 D20
 Overall Layout: 59"
 Nail Trim: #2N Standard

9028XBU WEDGE
 H39 W69 D 39
 Seat H20 D20
 Nail Trim: #2N Standard

9032PRBU POWER RIGHT ARM FACING RECLINER SOFA
 H39 W80 D39
 Arm H25 Seat H20 D20
 Overall Layout: 59"
 Nail Trim: #2N Standard

OPTIONS SHOWN:
 Arm: R-Rolled
 Back: B-Box Back
 Base: U-Upholstered



VIEW PORTFOLIO 9000
 SERIES ONLINE